

Case history brief:

| | |
|-----------------------|--|
| Location: | Bolton, United Kingdom |
| Application: | Tissue machine white water treatment |
| Capacity: | 250 m ³ /hr |
| Clarification: | SST removal |
| Chemicals: | Flocculant on all grades and primary coagulant depending on production grade |
| Installation: | 2000 |

Case history features:

The KWI Megacell MCH unit has been installed on mezzanine floor above the machine silo; all stainless steel construction. The MCH is able to reduce the SST from 1500 – 2000 mg/l to less than 50.

The mill has a second Megacell unit treating wash water from the de-inking plant.

